


Insulation Panel – Hood – Remove and Install (43 221 0)



Remove

- 1. Remove the panel.**
15 clips.

Install

- 2. Refit the components in reverse order.**