


Grille – Radiator – Remove and Install (43 232 0)



Remove

1. **Open the hood.**
2. **Remove the grille assembly.**
Disconnect the safety catch cable.

Install

3. **Refit the components in reverse order.**