

## **Display Assembly – Warning Indicator – Remove and Install (33 367 0)**

This is a non replaceable item forming part of the instrument cluster. Should this item fail the complete instrument cluster must be replaced (refer to Section 33-01 Operation Number 33 214 0).