


Glass – Instrument Cluster – Remove and Install (Instrument Cluster Removed) (33 226 4)



Remove



CAUTION: Do not place the glass/lens face down.

1. Remove the glass/lens (five screws).

Install

2. Refit the glass/lens.